

RHOPLEX™ I-545 Emulsion

Regional Product Availability	North America		
Description	RHOPLEX [™] I-545 Emulsion is a versatile all-acrylic aqueous vehicle suitable for overprint varnishes and letdowns for flexographic and gravure ink applications. It is a hard film former that offers a distinct combination of properties - good gloss, heat resistance and water resistance with fast drying speed. On press, RHOPLEX I-545 Emulsion has excellent transfer and printability with good resolubility for ease of clean-up.		
Key Features	 As an Overprint: Scuff resistance High inherent COF Good heat resistance, can be modified with zinc crosslinkers to enhance heat resistance Excellent clarity Good gloss Good water resistance As a Letdown Vehicle: With aluminum paste pigments for good stability Good solvent compatibility for flexo and gravure ink formulations 		
Typical Physical Properties	(These properties are typical but do not constitute specifications.)		
Properties	Property	Value Milky white emulsion	
	Appearance Solids, %	40.0	
	pH	8.5	
	Viscosity, cP	400 - 1500	
	Tg, °C	65	
	Acid number	75	
	Molecular weight	>200,000	
	Freeze/thaw stability	Yes, 5 cycles	
	VOC	No	
Compatibility Guidelines			

RHOPLEX I-545 Emulsion is compatible with the standard styrene/acrylics that are used in the graphic arts industry.

Typical Starting Point Formulations

Application: Overprint Varnish

	Scuff	Non-skid
RHOPLEX™ I-545 Emulsion	85.2	75.0
LUCIDENE™ 604 Emulsion	-	15.0
Water	9.6	5.0
Flexonic 600 ¹ polyethylene wax dispersion	5.0	-
Luciwax 37 emulsion	-	5.0
Patcote 811 ² defoamer	0.2	0.2
Total	100.0	100.0
TS, %	36.0	38.7
Viscosity, #2 Zahn cup, sec.	25-30	40
Static Slide Angle	21	35
Kinetic Slide Angle	10	20
Sutherland rub resistance	Pass 500 cycles	Pass 500 cycles

¹ Flexonic 600 polyethylene wax dispersion supplied by and a trademark of Lawter

² Patcote 811 defoamer supplied by and a trademark of Patco

Application: Heat Resistant Overprint Varnish

RHOPLEX™ I-545 Emulsion	82.0	41.0
RHOPLEX I-2183N	-	41.0
Water	7.3	12.8
Zinplex 15 ³ zinc ammonium carbonate complex	5.5	-
Luciwax 37 emulsion	5.0	5.0
PI-209 ³ defoamer	0.2	0.2
Total	100.0	100.0
TS, %	35.3	30.5
Viscosity, #2 Zahn cup, sec.	30-40	30-40
Heat resistance	Pass	Pass

³ Zinplex 153 zinc ammonium carbonate complexsupplied by and a trademark of Ultra Additives

³ PI-209 defoamersupplied by and a trademark of Ultra Additives

Application: Gloss and Offset Overprint Varnish

RHOPLEX™ I-545 Emulsion	71.0	80.3
RHOPLEX I-3000 (30%)	24.0	-
Water	-	10.0
Luciwax 37 emulsion	4.8	5.0
Isopropanol	-	3.0
Surfynol 104H ⁴ acetylenic diol surface active agent	-	1.5
Defoamer	0.2	0.2
Total	100.0	100.0
TS, %	39.2	35.0
Viscosity, #2 Zahn cup, sec.	60	40

⁴Surfynol 104H acetylenic diol surface active agent supplied by and a trademark of Air Products

Application: Metallic Inks Based on Aluminum Pigments

Typical Starting Point Formulations (cont.)

Premix and add:

RHOPLEX™ I-2074 Emulsion	75.0
Water	15.0
Ammonia Hydroxide	5.0
Add under moderate shear conditions:	
RHOPLEX I-545	5.0
Stapa Hydrolac W-60 n.l. ⁵ Aluminium pigment paste	0.2
Total	100.0
TS, %	38.7
Viscosity, #2 Zahn cup, sec.	40

Avoid extreme grinding to expose pigment surfaces that can produce gassing. Best results if allowed to equilibrate for 24 hrs. before use.

⁵ Stapa Hydrolac W-60 n.I. Aluminium pigment paste supplied by and a trademark of Obron

Food Legislation

FDA Regulation	Complies	Limitations	Opinion Date
21CFR175.105	Yes		08Jan13
(Adhesives)			
21CFR176.170		PROVIDED THAT THE FOOD	
(Components of paper	Yes with	CONTACT SURFACE OF THE	08Jan13
and paperboard in	Limitations	PAPER AND PAPERBOARD	
contact with aqueous and		COMPLIES WITH THE	
fatty foods)		EXTRACTIVES LIMITATIONS IN	
		21CFR176.170 PARAGRAPH (C).	
21CFR176.180			
(Components of paper	Yes		08Jan13
and paperboard in			
contact with dry food)			

Regulations may vary by city, state, country, or geographic region. Please contact the Dow Customer Service Group in your region for any additional, relevant regulatory information.

Product Stewardship	The Dow Chemical Company and its subsidiaries ("Dow") has a fundamental concern for all who make, distribute, and use its products, and for the environment in which we live. This concern is the basis for our Product Stewardship philosophy by which we assess the safety, health, and environmental information on our products and then take appropriate steps to protect employee and public health and our environment. The success of our Product Stewardship program rests with each and every individual involved with Dow products — from the initial concept and research, to manufacture, use, sale, disposal, and recycle of each product.				
Customer Notice	Dow strongly encourages its customers to review both their manufacturing processes and their applications of Dow products from the standpoint of human health and environmental quality to ensure that Dow products are not used in ways for which they are not intended or tested. Dow personnel are available to answer your questions and to provide reasonable technical support. Dow product literature, including safety data sheets, should be consulted prior to use of Dow products. Current safety data sheets are available from Dow.				
Medical Applications Policy	 NOTICE REGARDING MEDICAL APPLICATION RESTRICTIONS: Dow will not knowingly sell or sample any product or service ("Product") into any commercial or developmental application that is intended for: a. long-term or permanent contact with internal bodily fluids or tissues. "Long-term" is contact which exceeds 72 continuous hours; b. use in cardiac prosthetic devices regardless of the length of time involved ("cardiac prosthetic devices" include, but are not limited to, pacemaker leads and devices, artificial hearts, heart valves, intra-aortic balloons and control systems, and ventricular bypass-assisted devices); c. use as a critical component in medical devices that support or sustain human life; or d. use specifically by pregnant women or in applications designed specifically to promote or interfere with human reproduction. 				
Dow requests that customers considering use of Dow products in medic assessments may be conducted.				medical applications notify Dow so that appropriate	
	medical device or p suitable for the inte	rse or claim suitability of its products for s harmaceutical manufacturer to determine nded use. DOW MAKES NO WARR THE SUITABILITY OF ANY DOW S.	that the Dow product is saf ANTIES, EXPRESS C	e, lawful, and technically DR IMPLIED,	
Disclaimer	NOTICE: No freedom from infringement of any patent owned by Dow or others is to be inferred. Because use conditions and applicable laws may differ from one location to another and may change with time, the Customer responsible for determining whether products and the information in this document are appropriate for the Custo use and for ensuring that the Customer's workplace and disposal practices are in compliance with applicable law and other governmental enactments. Dow assumes no obligation or liability for the information in this document. NO WARRANTIES ARE GIVEN; ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED.				
	NOTICE: If products are described as "experimental" or "developmental": (1) product specifications may not be fully determined; (2) analysis of hazards and caution in handling and use are required; (3) there is greater potential for Dow to change specifications and/or discontinue production; and (4) although Dow may from time to time provide samples of such products, Dow is not obligated to supply or otherwise commercialize such products for any use or application whatsoever.				
Additional Information	North America U.S. & Canada:	1-800-441-4369 1-989-832-1426 +1-800-441-4369	Europe/Middle East	+800-3694-6367 +31-11567-2626	
	Mexico:		Italy:	+800-783-825	
	Latin America Argentina: Brazil:	+54-11-4319-0100 +55-11-5188-9000	South Africa	+800-99-5078	
	Colombia: Mexico:	+57-1-219-6000 +52-55-5201-4700	Asia Pacific	+800-7776-7776 +603-7965-5392	
www.dowplastics.com	This document is inte Published October, 2 © 2013 The Dow Ch				

